

# HS25KGP Suspended Baby Scale Owner's Manual





8535-M214-O1 Rev B 203 E. Daugh 03/15 Ph: 417-6

CARDINAL SCALE MFG. CO.
203 E. Daugherty, Webb City, MO 64870 USA
Ph: 417-673-4631 • Fax: 417-673-2153
www.detecto.com

Printed in USA

Technical Support: Ph: 866-254-8261 • tech@cardet.com

#### UNPACKING

- 1. Open box.
- 2. Remove top Styrofoam insert from box.
- 3. Next, remove S-hook from insert and set aside.
- 4. Grasp scale and remove from box.
- 5. Remove Pants (baby sling seat) from box.
- 6. Remove bottom Styrofoam insert from box.
- 7. Turn insert over to locate second S-hook.
- 8. Remove S-hook from insert and set aside.
- 9. Remove scale from plastic bag.
- Remove cardboard dowel between scale case and lower loop.
- 11. Scale is now ready to use.

#### **OPERATION**

- 1. Referring to Figure No. 1, install S-hooks on scale.
- 2. Unfold Pants (Baby Sling Seat).
- 3. Hang Pants on lower S-hook. See Figure No. 1.
- **4.** Referring to Figure No. 2, turn Zero Adjust Knob until dial pointer is reading "0".
- 5. Place baby in Pants.
- 6. The dial pointer will indicate the baby's weight.
- 7. Remove baby from Pants and re-zero scale if necessary.



NEVER leave a baby unattended in the Baby Sling Seat. Failure to maintain control of the baby at all times while they are in the Baby Sling Seat can result in serious injury to baby.



Figure No. 1



Figure No. 2

## **CARE AND CLEANING**

- **DO NOT** spray; water directly on the scale.
- DO clean scale using a damp, soft cloth and mild detergent.
   NOTE! Some types of paper towels may scratch the dial lens.
- DO NOT use acetone, alcohol, or other volatile solvents for cleaning.

### **PARTS LIST**

ITEM	QTY	PART NUMBER	DESCRIPTION
1	4	6600-1870	Lens Screw
2	1	6600-1871	Lens
3	2	6600-1872	S-Hook
4	1	HSPANT	Pants (Baby Sling Seat)