

# 190 Blue Front Enclosure

Part No. 8400-D010-18



*Cardinal Scale's 190 STORM weight indicator shown with optional blue front enclosure.*

*Part No. 8400-D010-18*

## IDEAL FOR FOOD PROCESSING

### BLUE ULTRA-TOUGH FRONT ENCLOSURE

Cardinal Scale's 190 STORM digital weight indicator features a rugged polycarbonate enclosure and capacitive touch keys for total protection against sharp objects. The 190 is impact resistant for ultimate durability in harsh environments.

### OPTIMAL HEALTH AND SAFETY

In the unlikely event during food production that anything breaches the polycarbonate enclosure, the distinctive blue color of the optional 8400-D010-18 front cover facilitates early visual detection and removal to prevent food contamination. The see-through IP69K watertight blue front enclosure provides the ultimate in food safety.

### CAPACITIVE TOUCH KEYS

The 190 indicator's unique capacitive touch keys allow the front of the panel to be constructed as a single piece. The keypad senses the operator's finger from the inside of the weight indicator's enclosure.