

FOOD SERVICES PRODUCTS

DETECTO scales for the food services department come in a variety of sizes and styles



MCS-20P



Enterprise
POSTLOGISTICS SCALES



DL1030P



PT-25



PS4



EB-150-185B



420-2000

DETECTO[®]

DETECTO HAS THE RIGHT SCALE FOR YOUR COMMERCIAL KITCHEN OR CAFETERIA

DETECTO has the right scale for you, from simple portion scales to integrated and networked price computing scales.

Founded in the foodservice industry in 1900, DETECTO's scales are designed to serve a wide variety of needs in the commercial foodservice business. Our price computing scale networks with your inventory to print labels, bar codes, ingredients, or anything else. Our portion scales are easy to read and clean, and our precision scales offer unmatched accuracy down to milligrams.

DL1030P

Price Computing Scale with Integrated Label Printer



DETECTO's DL series networkable price computing scales with integral label printers features 5,990 PLUs, 30 lb x 0.01 lb or 60 lb x 0.02 lb capacity, 12.8 in W x 8.9 in D stainless steel platform, inventory reporting capabilities by PLU, multiple connectivity ports, alphanumeric display, 4 LED display windows and 1 dot matrix text screen, NTEP legal-for-trade certification, and they are available with or without a tower pole display. 50 label types are available via included software. Label rolls are available from DETECTO in single rolls or by the case.

MCS-20P

Hanging Dial Scale with Stainless Steel Bowl



The MCS series hanging dial scales are built for commercial use in grocery store produce sections, commercial kitchens, and general foodservice use. DETECTO offers the MCS mechanical scale with a galvanized scoop and chains, bowl suspended by a steel bow, and also the dial by itself with two S-hooks. The large 8-inch-diameter dial is furnished with easy-to-read black graduations and numerals and a red knife pointer that indicates weight fast and accurately. The dial mechanism is protected by a clear lens while plastic housing eliminates dust and scratches. The MCS produce scale is offered in 20-lb and 40-lb capacities and includes two steel industrial-grade S-hooks (top and bottom).

APS15

Enterprise Retail Point-Of-Sale Scale



DETECTO's Enterprise series retail point-of-sale (POS) scales integrate with most point-of-sale systems for checkout applications and to personal computers for many other applications that require weight data. The Enterprise series scales offer optional NTEP legal-for-trade wireless capability for ease of data integration. The scales come in a multitude of platform sizes to choose from ranging from 6 x 10 inch/15 x 25 cm up to 18 x 18 inch/46 x 46 cm and six different capacities ranging from 160 oz x 0.1 oz up to 250 lb x 0.1 lb/125 kg x 0.05 kg. The scales are NTEP legal-for-trade and come with four connectivity ports (1 USB-B and 3 RS-232 serial).

420-2000

Digital Precision Balance Scale with up to 2000 g Capacity and 20 mg Precision



DETECTO's digital precision balance scales are precise and flexible, measuring in a wide variety of units for many applications where accuracy is demanded, such as weighing food, patient samples, medication, and other critical materials. The scale has a built-in rechargeable battery and a removeable air shield for precise measurement. The stainless steel platform size is 5.7 in W x 4.5 in D.

PT-25

Petite Top Loading Dial Scale



Available in baked enamel or stainless steel, DETECTO's PT series is the petite top loader product line of choice. They feature sturdy construction, stability, convenient weight viewing angle, temperature compensation for dependable accuracy and easy readability. Available in a number of different capacities, these top loaders can be used for a variety of applications. Most models feature a 5.75-inch square stainless steel platform. These economically priced scales are the perfect solution for weighing portions in food-service, or just about anything else.

EB-150-185B

Stainless Steel Bench Scale with Column-Mounted Display



DETECTO's EB bench scales with 185 Rival weight indicators feature rechargeable battery power allowing them to be moved easily to multiple locations, bold 1-inch/25-mm high backlit LCD for high-visibility readouts, 3 platform sizes and 5 capacities available. Capacities range from 15 lb/6 kg up to 300 lb/150 kg and the EB series is NTEP, OIML, and Measurement Canada legal for trade. The EB bench scales feature the strength and durability of a beautiful stainless steel scale base and column combined with the a bright, adjustable display.

PS4

Compact Portion Scale Takes up Minimal Counter Space



DETECTO's PS4 portion scale features a smooth, molded stainless steel body, lift-off stainless steel commodity tray, and sealed membrane keypad, making it incredibly easy to clean and simple to operate. Featuring a 0.8-inch (20-mm) high 5-digit LCD display and a 5.9 x 4.75 inch (15 x 12 cm) platform with a capacity of 4 lb, this scale is ideal for cafeterias, restaurants, delis and pizza parlors. The PS4 is accurate to 0.1 oz and NSF certified.

DETECTO reserves the right to improve, enhance, or modify features and specifications without prior notice.

SOLD BY:

DETECTO®

102 East Daugherty St., Webb City, MO 64870 USA
Toll-Free: (800) 641-2008 E-mail: detecto@cardet.com
www.Detecto.com