



Cardinal Scale  
model HSDC-500  
digital hanging scale  
with pushbutton tare

## HSDC Series

### Digital Hanging Scales



LEGAL FOR TRADE

Class III certificate  
All HSDC models are NTEP  
except model HSDC-500



Stainless Steel Eyehook  
and Hook Included for  
Versatile Weighing Use

- 1-inch-High Bold LCD Readouts for Easy Visibility
- Aluminum Alloy Enclosure for Lightweight Strength
- Up to 500-lb and 100-kg Capacities Available
- 9 Different Models to Select From
- Battery Powered for Convenient Portable Weighing

# Cardinal Scale's HSDC Series Digital Hanging Scales

Fishing • Curbside Recycling Collection • Butchery/Meat Processing • Industrial Applications • Supermarkets



1-inch/25-mm-high bold LCD display  
Lightning-fast and accurate digital readouts

Model HSDC-20KGP  
includes stainless steel bowl

Stainless steel bowl measures  
13.7 in diameter x 4.4 in H /  
34.8 cm diameter x 11.2 cm H



HSDC-20	HSDC-40	HSDC-100	HSDC-200	HSDC-500	HSDC-20KG/ HSDC-20KGP	HSDC-40KG	HSDC-100KG
20 lb x .01 lb	40 lb x .02 lb	99.95 lb x .05 lb	200 lb x .1 lb	500 lb x .2 lb	20 kg x .01 kg HSDC-20KGP features stainless steel pan	40 kg x .02 kg	99.95 kg x .05 kg
<b>Scale Dimensions</b>		Width: 8.5 in / 21.6 cm Depth: 5.1 in / 13.0 cm Height: 4.3 in / 10.9 cm					
<b>Overall Dimensions</b> (with hooks)		Width: 8.5 in / 21.6 cm Depth: 5.1 in / 13.0 cm Height: 14.0 in / 35.6 cm (including eyehook and hook)					
<b>LCD Display Dimensions</b>		Width: 3.3 in / 8.4 cm Height: 1.1 in / 2.8 cm					
<b>LCD Digit Size</b>		Width: 0.5 in / 1.3 cm Height: 1.0 in / 2.5 cm					
<b>Product Weight</b>		5.8 lb / 2.6 kg (10 lb / 4.5 kg with model HSDC-20KGP's stainless steel bowl and hanging assembly)					
<b>Shipping Weight</b>		7.2 lb / 3.3 kg (including packaging)					
<b>Power</b>		6 C batteries (not included)					
<b>Operating Temperature</b>		+14° to 104°F (-10° to +40°C)					
<b>Zero</b>		Established during setup and maintained automatically to ± 1/4 graduation					
<b>Auto Zero Range</b>		5 and 0 through 9 graduations					
<b>Calibration Method</b>		Digital, keypad entered; calibration stored in nonvolatile memory					
<b>Tare</b>		Push button, 100% of full scale capacity					
<b>Annunciators</b>		Center of zero, motion, net, low battery, over capacity					
<b>Buttons</b>		ON/ZERO, NET, TARE, GROSS, OFF					
<b>Load Cell</b>		Cardinal Scale model CMBC constant moment beam cell					
<b>Sample Rate</b>		1 - 12 samples per second, selectable					
<b>Auto Shut-off</b>		Power saving mode selectable from 1 to 9 minutes					
<b>NTEP Approval</b>		03-030 Accuracy Class III (applies to all HSDC models except HSDC-500)					

Cardinal Scale reserves the right to improve, enhance or modify features and specifications without prior notice. All registered trademarks are the property of their respective owners.



102 East Daugherty St., Webb City, MO 64870 USA  
Toll-Free: (800) 441-4237 E-mail: cardinal@cardet.com  
www.CardinalScale.com

**SOLD BY:**

