

## BIGITAL PS7

Ideal for restaurants, cafeterias, delis, salad bars, and pizza parlors

- 8 in W x 5 in D /
  20 cm W x 13 cm D
  stainless steel
  platform
  - 5 units of measure, including 3,000 g x 1 g and 7 lb x 0.1 oz
- Internal rechargeable battery pack included
- Affordable price and high performance
- Portable and compact (only takes up minimal counter space)
- Optional oversized 9.5 in W x 6.8 in D platform available

## CHECKWEIGHING

LCD changes color based on Under/Accept/Over preset target weights that you select

**NSF** 





**COMPACT SIZE** 

DIGITAL SPEED AND ACCUBACY

Bold, easy-to-read, 1-inch/25-mm high backlit LCD with checkweighing mode



MODEL

Zero

Power

Capacity

**Platform Size** 

Construction

**Battery Life** 

Tare (Zero)

Humidity

Features

Keys

Temperature

Certification

**UPC Code** 

**Shipping Weight** 

Weight Display

**Overall Dimensions** 



NSF Certified

Comes with UL/CSA-listed wall plug-in power supply and internal rechargeable battery pack

PS7

7 lb x 0.1 oz, 112 oz x 0.1 oz, 112 oz x 1/8 oz, 3000 g x 1 g, 7 lb x 0.005 lb

8.03 in W x 7.87 in D x 2.44 in H / 204 mm W x 200 mm D x 62 mm H

8.02 in W x 4.96 in D / 204 mm W x 126 mm D

ABS plastic enclosure with stainless steel platform cover

1.0 in / 25 mm high backlit LCD, 5 digit with fraction

Established on power up routine and maintained by auto-zero circuitry

115 VAC 50/60Hz or 230 VAC 50/60 Hz powering a 15 VDC 300 mA

wall plug-in UL/CSA listed power supply (included) or one internal

rechargeable battery pack (included)

20 hours of continuous use with fully charged battery pack 100% of scale capacity

40° to 105°F / 5° to 40°C

25%~95% RH

Low battery indicator, power saving selectable timing, auto shut-off

ON/OFF, MODE/OK, UNIT/▶, TARE/☆/▲

NSF approved

4 lb / 1.8 kg

809161128307

DETECTO's PS7 digital portion scale can be used wherever food is weighed, portioned, or dispensed. The PS7 offers five different units of measure and you can disable different units of measure if they are not needed. The display is angled upward for easy viewing. The display backlight will be turned on during weighing and will automatically turn off 5 seconds after the weight has been removed from the scale.

> The scale's Tare feature lets you tare/zero the weight of a container up to the full capacity of the scale. By using the checkweighing feature, you can select under and over weight limits for quickly checking food portion weights. The LCD will turn red for over weights, green for acceptable weights, and the backlit will turn off for under weights. The PS7 comes in attractive retail packaging.



**DETECTO** www.Detecto.com

102 E. Daugherty, Webb City, MO 64870 USA Ph: 417-673-4631 or 1-800-641-2008 Fax: 417-673-2153 DETECTO reserves the right to improve, enhance, or modify features and specifications without prior notice.

## **SOLD BY:**

© Copyright 2019 Cardinal Scale Mfg. Co. • Printed in USA • CAR/00/0919/D294