



SOLAR POWERED HANGING SCALE



LEGAL FOR TRADE

- Exclusive solar powered design for optimal efficiency
- 30 lb / 15 kg capacity for versatile weighing use
- Never replace a battery – completely solar powered
- Digital speed for instantaneous weight readouts
- Pinpoint accuracy to 0.01 lb / 0.005 kg
- NTEP legal for trade (Certificate of Conformance No. 15-009)
- Large 1-inch-high, easily-visible LCD readouts
- Easy to operate – no buttons to press
- Automatic zero tracking
- Includes stainless steel produce pan, bow, and two industrial-grade steel S hooks

DETECTO Model SCS30
Solar Hanging Scale

*From the name brand in foodservice
scales since 1900... DETECTO*



**FARMERS
MARKETS**



**PRODUCE
SECTIONS**



**HARDWARE
STORES**

 **DETECTO**
www.Detecto.com




SOLAR POWERED HANGING SCALE

DETECTO's exclusive digital solar hanging scale is powered completely by light and never requires battery replacement. The model SCS30 is NTEP approved legal for trade making it ideal for grocery stores, farmers markets, hardware stores, and roadside produce stands where customers pay by weight. The 30 lb/15 kg capacity and 0.01 lb/0.005 kg divisions offer you pinpoint measurement accuracy. The bold 1-inch-high LCD displays instant digital readouts. A stainless steel produce pan, hanging assembly, and two S-hooks are included, so the solar-powered scale is ready to use right out of the box, just add light!



Optional portable stand for DETECTO's SCS30 digital solar scale model HS-STAND

(24 x 24 in base x 72 in H / 61 x 61 cm base x 182 cm H)

The SCS30 should not be left in direct sunlight and requires a minimum of 400 lux for operation.

Capacity	30 lb x 0.01 lb / 15 kg x 0.005 kg
Units Conversion	lb / kg
Power	Solar cell
Solar Type	Amorphous silicon solar panel
Lighting Requirements	Minimum 400 lux
Recommended Placement	Indoors - direct light Outdoors - indirect light (do not operate in direct sunlight)
LCD Digits	Five-digit, seven-segment, 1.0 in / 25 mm high bold digits
LCD Display Size	3.9 in W x 1.4 in H / 9.9 cm W x 3.6 cm H
Annunciators	lb, kg, zero, solar charge status
Button	Zero/Tare button (located on bottom of scale)
Certification	NTEP legal for trade
Accuracy Class	III
NTEP Certificate Number	15-009
Temperature Range	32° F to 104° F (0° C to 40° C)
Construction	Polycarbonate scale, stainless steel pan and bow
Includes	SCS30 digital scale, 2 S-hooks, 1 bow assembly, 1 ring assembly, 2 pan bow nuts, 2 wing nuts 5/16-18, 1 pan with 3 drainage holes
Scale Dimensions	8.8 in diameter x 3.8 in D / 22.4 cm diameter x 9.7 cm D (round portion)
Overall Dimensions	13.5 in diameter x 30 in H / 34.2 cm diameter x 76.2 cm H (including all components)
Pan Dimensions	11.5 in diameter x 4.1 in H / 29.2 cm diameter x 10.4 cm H
Product Weight	4.5 lb / 2.0 kg
UPC Code	809161194401

Detecto Scale reserves the right to improve, enhance, or modify features and specifications without prior notice.



DETECTO
www.Detecto.com

102 E. Daugberty, Webb City, MO 64870 USA
Ph: 417-673-4631 or 1-800-641-2008 Fax: 417-673-2153

SOLD BY: