



Consistent Portion Control | T-D Series

- Available in 5-lb and 2-lb Capacities
- 8-inch (20-cm) Diameter Fixed Dial
- Durable White Baked Enamel Finish
- Roomy Stainless Steel Platform
- Air Dashpot Shock Absorber
- Temperature-Compensated Springs



Mechanical Dial Scales for High-Volume Weighing

DETECTO's durable top loading dial scales feature temperature-compensated springs which are maintenance free and the scales don't require electricity, so they can be used anywhere. The phosphate-plated internal steel parts and 8.75-inch x 8.75-inch (22-cm x 22-cm) stainless steel platform resist corrosion. The convenient dial viewing angle and air dashpot provide instant weight readouts that are easily visible. The air dashpot is ideal for fast, high-volume weighing applications and reduces oscillation of the indicator pointer.





MODEL	T-2-D	T-5-D
Capacity	32 oz x 1/8 oz	5 lb x 1/2 oz
Platform Size	8.75 in x 8.75 in / 22 cm x 22 cm	
Platform Construction	Stainless steel	
Overall Construction	White baked enamel external finish and phosphate-plated internal steel parts	
Dial	8 in / 20 cm diameter fixed dial	
Overall Dimensions	8.75 in W x 10.5 in D x 10.5 in H / 22 cm W x 27 cm D x 27 cm H	
Air Dashpot	Yes, with adjustment screw (reduces indicator needle oscillation for faster readings)	
Operating Temperature	14°F to 104°F / -10°C to 40°C	
UPC Code	809161193503	809161193602
Shipping Weight	8 lb / 4 kg	

Detecto Scale reserves the right to improve, enhance, or modify features and specifications without prior notice.

A Division of Cardinal Scale Manufacturing Co.

203 E. Daugherty, Webb City, MO 64870 USA
Ph: 417-673-4631 or 1-800-641-2008 Fax: 417-673-5001

www.Detecto.com



SOLD BY:

Mobile: m.detecto.com